

Hitachi Construction Machinery

**SELECTED PARTS**

**HITACHI**

Reliable solutions

# Hitachi Construction Machinery **SELECTED PARTS** Catalog

**GET  
PARTS**

**UNDERCARRIAGE  
PARTS**



promotion video


# ABOUT Hitachi Construction Machinery SELECTED PARTS\*1

\*1 Hereinafter called "SELECTED PARTS".

SELECTED PARTS is the new parts line-up of Hitachi Construction Machinery for after-sales service support. It covers wide range of our machines. Parts warranty is same as Hitachi Genuine Parts but price is lower.

-  Excellent durability under the working environments of heavy equipment
-  Designed based on Hitachi Construction Machinery Company's technology
-  The warranty program provides the equivalent term with Hitachi Genuine Parts \*2
-  Global sales network

\*2 This warranty program would not apply to normal wear and tear of the product. Please contact to Hitachi authorized dealers for the details of warranty conditions.



GET PARTS



## Example of utilization of **SELECTED PARTS** to lower the lifecycle cost of a machine

**Delivery of a machine**

Since the bucket teeth was worn-out and work efficiency had started to drop, the bucket teeth were replaced.



It was found out that some undercarriage parts has worn-out during a special machine-visit inspection.



### **POINT 01**

A wide variety of bucket consumable parts are prepared and available. It is possible to change certain parts to ones most suitable to each application.

Parts will be replace before becoming an actual failure.



### **POINT 02**

Since the price of **SELECTED PARTS** are lower than Hitachi Genuine Parts, it is economically feasible to replace parts in a preventive manner.

Since the machine had been engaged in heavy duty work for few days, few of the track links has cracked. They were replaced as individual parts as oppose to the track link assemble replacement.



### **POINT 03**

Since various parts are available as individual parts or sub-assembly, you do not need to replace the whole track link assemblies.

**Replacement of the machine**

# LIFECYCLE OF PARTS

**UNDERCARRIAGE PARTS**

# Five Features of SELECTED PARTS

## Features

Material

Manufacture

Configuration

Warranty

Supply

## 5 FEATURES

FEATURE

01

**Material** Optimal anti-wear, impact resistance and lubricating property

FEATURE

02

**Manufacture** Strict manufacturing processes and quality control

FEATURE

03

**Configuration** Design based on Hitachi Construction Machinery company's technology

FEATURE

04

**Warranty** The warranty program provides the equivalent term with Hitachi Genuine Parts

FEATURE

05


**Supply** Global supply system

FEATURE 01 FEATURE 02

## Material / Manufacture

Excellent durability required for the heavy equipment's working environments

	Genuine parts	SELECTED PARTS	Imitation or will-fit parts
Anti-wear quality/ Impact resistance			




FEATURE 03

## Configuration

Designed based on Hitachi Construction Machinery Company's technology

Shapes calculated to maintain sufficient strength to prevent early performance degradation (wear and cracking).



FEATURE 04

## Warranty

We secure the parts with warranty equivalent to Hitachi Genuine Parts

The warranty term is for 1 year/unlimited hour from the date the parts were installed on the machine or purchased.

Install the parts on the machine and start warranty!

**1 YEAR  
UNLIMITED**  
1 year warranty.



FEATURE 05

## Supply

Hitachi Construction Machinery's Global sales network

You can purchase from Hitachi Construction Machinery dealers around the world when needed.  
Please contact your nearest Hitachi Construction Machinery dealer.

● Hitachi Construction Machinery's Global supply ●



# UNDERCARRIAGE PARTS

## List of undercarriage parts

Idler

Sprocket

Upper roller

Lower roller

Track link



### Regarding icons in the text;

**Mini**

“Mini” indicates 1.4 to 8 ton excavators.

Examples: ZX14, ZX85, etc.

**Mid**

“Mid” indicates 10 to 35 ton excavators.

Examples: ZX110, ZX270, etc.

**Large**

“Large” indicates 45 to 87 ton excavators.

Examples: ZX450, ZX890, etc.



## Idler

**Mini**

**Mid**

**Large**

Idlers are to adjust the track link tension, which make track links to run on the rollers smoothly by expansion and contraction mechanism, and prevent the machine from falling.

## Sprocket

**Mini**

**Mid**

**Large**

Sprockets play an important role to convey rotating force to the track links. If the sprocket teeth is worn out, the traveling force of the machine will get weaker and premature wearing of track links will occur. The teeth of SELECTED PARTS sprockets are carefully heat treated to increase their anti-wear quality.



## Application example: Forestry operation

In forestry operation, undercarriage parts worn out faster, so **SELECTED PARTS** becomes handy due to its reasonable pricing.

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

**UNDERCARRIAGE  
PARTS**

## Upper roller

Mini

Mid

Large

Upper rollers rotate and guide track links so that the track links move smoothly under various ground conditions. If they don't rotate normally, the track links will be worn out prematurely.

**SELECTED PARTS** upper rollers are deeply heat treated and their metal texture is fine and uniform.



## Lower roller

Mini

Mid

Large

Lower rollers play an important role to guide the track links so that the links move smoothly under various ground conditions. However, the lower rollers are prone to wearing and breakage. If they get worn beyond a certain limit, contact with track links becomes skewed, which will lead to premature wearing of the links.

**SELECTED PARTS** lower rollers are deeply heat treated and their metal texture is fine and uniform.

## Track link

Mini

Mid

Large

Track links play an important role in the traveling system and it is necessary to frequently adjust their tension. If they get worn beyond a certain limit, wearing will get faster. Eventually, they get derailed. The right and left end sections of **SELECTED PARTS** track links are carefully heat treated to increase their anti-wear property.

\* Track;Link (Unit) are available as individual parts so that a single section or an inner part can be replaced. Refer to page 16 for details.



# GET PARTS

## List of GET parts

Tooth adapter

Tooth point

Side cutter

Shroud

Lock pin and rubber



### Regarding icons in the text;

**Mini**

“Mini” indicates 1.4 to 8 ton excavators.

Examples: ZX14, ZX85, etc.

**Mid**

“Mid” indicates 12 to 35 ton excavators.

Examples: ZX110, ZX270, etc.

**Large**

“Large” indicates 45 to 87 ton excavators.

Examples: ZX450, ZX890, etc.



### Tooth adapter

**Mini**

**Mid**

**Large**

For fastening teeth to the bucket.

### Tooth point

**Mini**

**Mid**

**Large**

Used for general excavation or making the surface of a slope smooth. It is possible to change attachments for each application.

Heat-treated material or cemented carbide is used to increase anti-wear property.



**Application example:  
Mining**

Although bucket parts get worn or broken much faster in mining operation, the maintenance cost can be kept reasonable thanks to **SELECTED PARTS**.

ZX-1,3,5,6  
type  
**1.4~8t**

ZX-1,3,5,6  
type  
**12~35t**

ZX-1,3,5,6  
type  
**45~87t**

**Lock pin and rubber**

Mini Mid Large

Prevent tooth adapters from falling out.



**Side cutter**

Mini Mid Large

Improves cutting ability of the side plates of the bucket and also prevent the side plates from wearing.

**Shroud**

Large

Protect the bucket bottom lip when the machine works under a hard duty environment.



# PARTS LIST

List of parts



# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

## Idler

### For mini/small-size excavators ( ZX-1, 3, 5, 6 type 1.4~8t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX14-3, ZX16-3, ZX17U-2, ZX17U-5A, ZX17U-5N, ZX18-3, ZX19-5A, ZX19U-5A	9312918PS	9312918
ZX20U, ZX20UR, ZX20U-5A, ZX26U-5A, ZX26U-5N, ZX27-3	9314258PS	9314258
ZX27-2, ZX27U-3, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3,	9261429PS	9261429
ZX27U-3, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-5A, ZX33U-5A, ZX35U-5A, ZX38U-5A, ZX40UR-5B	9269094PS	9269094
ZX40U, ZX50U, ZX40U-2, ZX50U-2, ZX55UR-2, 40U-3, ZX48U-3, ZX50U-3, ZX52U-3F, ZX55UR-3	XP00000329PS	9237507
ZX40U-3, X49U-3U, ZX48U-3, ZX50U-3, ZX52U-3, ZX55UR-3, ZX50U-5A, ZX55U-5B, ZX40U-5A	YD60007381PS	YD60007381, 9318048
ZX55UR, ZX60-5A	9133370PS	9133370
ZX60USB-5N, ZX65USB-5A	9318338PS	9318338
ZX70, ZX70LC, ZX75UR, ZX80LCK, ZX70-3, ZX70LC-3, ZX75UR-3, ZX75US-5A, ZX80LCK-3, ZX85US-3, ZX85US-5A, ZX70-5A	9154166PS	9154166

### For mid-size excavators ( ZX-1, 3, 5, 6 type 10~35t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX110-1/3, ZX120-1/3/5B/6	XP00000237PS	9273554
ZX160, ZX160LC-3, ZX180LC-1/3, ZX200, ZX200-3(*), ZX230, ZX240-3(*)	XP00000239PS	9242964
ZX160-5B/6, ZX160LC-5A/5B/5G/6, ZX180-5B, ZX200-3(*), ZX200-5A/5B/5G/6, ZX240-3(*), ZX240-5A/5B/5G/6	XP00000264PS	9303011
ZX270, ZX270-3(*), ZX330-3(*)	XP00000243PS	9245616
ZX270-3(*), ZX280-5B/5G, ZX300-5A/6, ZX330-3(*), ZX330-5A/5B/5G/6	XP00000265PS	YA60018462

### For large-size excavators ( ZX-1, 3, 5, 6 type 45~87t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX450, ZX480/H, ZX500-1/3, ZX520-3/3F, ZX530-5A, ZX600, ZX650	9137270PS	9137270
ZX450-3/3F, ZX470-3/3F, ZX470LC-5A/5B/5G, ZX480-5B, ZX490-5A	9244297PS	9244297
ZX800/3, ZX850-3F, ZX850, ZX870-5B/5G, ZX870H-3/3F/5B/5G, ZX870LC-5B/5G, ZX890-5A	YA00026683PS	YA00026683
ZX650LC-3/5B, ZX670LC-5B/5G, ZX670LCR-3/3F, ZX690-5A	YA00026685PS	YA00026685

\* Attention : SELECTED PARTS may vary depends on machine model and serial number.

To confirm appropriate SELECTED PARTS for your machine, please contact your local dealer.

Precaution | We recommend that the left and right idlers should be replaced at the same time.

# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

## Sprocket

### For mini/small-size excavators ( ZX-1, 3, 5, 6 type 1.4~8t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX14-3, ZX16-3, ZX17U-2, ZX17U-5A, ZX18-3, ZX19-5A	2056268PS	2056268
ZX26U-5A, ZX26U-5N	2054262PS	2054262
ZX27-3, ZX35, ZX35KD, ZX40UR, ZX30U	2039666PS	2039666
ZX27U-3, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-5A, ZX33U-5A, ZX35U-5A, ZX38U-5A, ZX40UR-5B	2055869PS	2055869
ZX30, ZX27U-2, ZX27U-3, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-2, ZX35U-2, ZX30UR-2, ZX40UR-2	1032265PS	1032265
ZX40U-3, ZX48U-3, ZX50U-3, ZX52U-3, ZX55UR-3, ZX50U-5A, ZX55U-5B, ZX40U-5A, ZX55UR-5B	1036618PS	1036618
ZX60-5A, ZX60-5G, ZX60USB-3, ZX65USB-3F, ZX60USB-5N, ZX65USB-5A, ZX68USR-5A	2054155PS	2054155
ZX70-3, ZX70LC-3, ZX75US-5A, ZX80LCK-3, ZX85US-3, ZX85USB-5A	1033840PS	1033840
ZX70-5A, ZX70LC-5A, ZX70-5G, ZX70LC-5G	YD00002183PS	YD00002183

### For mid-size excavators ( ZX-1, 3, 5, 6 type 10~35t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX110-1/3, ZX120-1/3	XP00000228PS	1010325
ZX120-5B/6	XP00000266PS	1028027
ZX160, ZX160LC-3(*), ZX180LC-1/3, ZX180-5B, ZX200	XP00000229PS	1018740
ZX160-5B/6, ZX160LC-3(*)/5A/5B/5G/6, ZX200-3/5A/5B/5G/6	XP00000230PS	1033091
ZX230	XP00000231PS	1010203
ZX240-3/5A/5B/5G/6	XP00000232PS	1032489
ZX270, ZX330	XP00000234PS	1022168
ZX270-3, ZX280-5B/5G, ZX300-5A/6	XP00000233PS	1033227
ZX330-3/5A/5B/5G/6	XP00000235PS	1033163

### For large-size excavators ( ZX-1, 3, 5, 6 type 45~87t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX450-3/3F, ZX460LCH, ZX470-3/3F/5B/5G, ZX470LC-5A/5B/5G, ZX480LCK-5B, ZX490H-5A	1010956PS	1010956
ZX450MT, ZX480MT, ZX500LC/3/3F, ZX520-3/3F/5B, ZX530LCH-5A, ZX600, ZX650	4639374PS	4639374
ZX650LC-3/5B, ZX670LCH-3/3F/5B/5G, ZX690LCH-5A, ZX800, ZX850-3/3F, ZX870H-3/3F/5B/5G, ZX890-5A	YA00001980PS	YA00001980

\* Attention : SELECTED PARTS may vary depends on machine model and serial number.  
To confirm appropriate SELECTED PARTS for your machine, please contact your local dealer.  
Precaution | We recommend that the left and right sprockets should be replaced at the same time.

# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

## Upper roller

### For mini/small-size excavators ( ZX-1, 3, 5, 6 type 1.4~8t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX60-5A, ZX60-5G	4679884PS	4679884, 4392416
ZX30U, ZX27U-2, ZX27U-3, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-2, ZX35U-2, ZX30UR-2, ZX40UR-2, ZX35B	9237948PS	9237948
ZX40U, ZX50U, ZX40U-2, ZX50U-2, ZX55UR-2, ZX40U-3, ZX48U-3, ZX50U-3, ZX52U-3, ZX55UR-3, ZX40U-A, ZX50U-A	9239529PS	9239529
ZX27U-3, ZX30U-3, ZX33U-3, ZX30U-5A, ZX33U-5A, ZX35U-5A, ZX38U-5A, ZX40UR-5B, ZX40U-3, ZX48U-3, ZX50U-3, ZX55UR-3, ZX40U-5A, ZX55UR-5B	4718355PS	4718355
ZX70, ZX75UR, ZX80LCK, ZX70-3, ZX75UR-3, ZX75UR-5B, ZX80LCK-3, ZX85US-3, ZX85US-5A, ZX70-5A, ZX85USBLC-3,	XP00000362PS	9153288

### For mid-size excavators ( ZX-1, 3, 5, 6 type 10~35t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX110-1/3, ZX120-1/3/5B/6	XP00000257PS	9160680
ZX160, ZX180LC, ZX200, ZX230	XP00000303PS	9134245
ZX160-5B/6, ZX160LC-3/5A/5B/5G/6, ZX180LC-3, ZX180-5B, ZX200-3/5A/5B/5G/6, ZX240-3/5A/5B/5G/6	XP00000259PS	9234984
ZX270, ZX330	XP00000304PS	9257022
ZX270-3, ZX280-5B/5G, ZX300-5A/6, ZX330-3/5A/5B/5G/6	XP00000261PS	9245117

### For large-size excavators ( ZX-1, 3, 5, 6 type 45~87t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX450, ZX450LC, ZX460LCH, ZX470-5G/5A/5G, ZX490H-5A, ZX490-5A	9099140PS	9099140
ZX450MT, ZX480MT, ZX500LC-3/3F, ZX520LCH-3/3F/5B, ZX530LCH-5A, ZX600, ZX650H	9109492PS	9109492
ZX450-3/3F, ZX470-5B	9250478PS	9250478
ZX650-3, ZX670-3/3F/5B/5G, ZX690-5A, ZX800	9078675PS	9078675
ZX850-3/3F, ZX870-5B/5G, ZX890-5A	4638433PS	4638433

\* Attention : SELECTED PARTS may vary depends on machine model and serial number.

To confirm appropriate SELECTED PARTS for your machine, please contact your local dealer.

Precaution | We recommend that the left and right upper rollers should be replaced at the same time.

# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

## Lower roller

### For mini/small-size excavators ( ZX-1, 3, 5, 6 type 1.4~8t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX14-3, ZX14-3CKD, ZX16-3, ZX17U-2, ZX17U-5A, ZX17U-5N, ZX18-3, ZX19-5A, ZX19U-5A	YD00004084PS	YD00004084
ZX30U, ZX35U-A, ZX27U-2, ZX27U-3, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-2, ZX35U-2, ZX35U-2U, ZX30UR-2, ZX40UR-2	9237937PS	9237937
ZX30U, ZX29U-3, ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-5A, ZX33U-5A, ZX35U-5A, ZX38U-5A	YD00008528PS	YD00008528, YD00005461
ZX50, ZX40U, ZX50U, ZX40U-2, ZX50U-2, ZX40U-3, ZX48U-3, ZX48U-3F, ZX50U-3, ZX52U-3, ZX55UR-3, ZX50U-5A, ZX55U-5B, ZX40U-5A, ZX40U-5B, ZX55USR-5A, ZX40U-A, ZX50U-A	YD00010174PS	YD00010174
ZX40, ZX55UR, ZX40U, ZX50U, ZX60-HCMC, ZX60-5A, ZX60-5G, ZX40U-A, ZX50U-A	4357785PS	4357785
ZX60USB-365USB-3F, ZX60USB-5N, ZX65USB-5A, ZX68USR-5A	4671711PS	4671711
ZX75US-5A, ZX85US-5A	YD00003751PS	9182805, YD00003751
ZX70, ZX70-5A	9170017PS	9170017

### For mid-size excavators ( ZX-1, 3, 5, 6 type 10~35t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX110-1/3, ZX120-1/3/5B/6	XP00000253PS	9132600
ZX160/5B/6, ZX160LC-3/5A/5B/5G/6, ZX180LC-1/3, ZX180-5B, ZX200-1/3/5A/5B/5G/6, ZX230, ZX240-3/5A/5B/5G/6	XP00000254PS	9184516
ZX270, ZX330	XP00000263PS	9168173
ZX270-3, ZX280-5B/5G, ZX300-5A/6, ZX330-3/5A/5B/5G/6	XP00000256PS	9253782

### For large-size excavators ( ZX-1, 3, 5, 6 type 45~87t )

Applicable Models	SELECTED PARTS No.	Genuine Parts No.
ZX450, ZX450-3/3F, ZX470H-3/3F/5B, ZX470LC-5A/5B/5G	YA00005129PS	YA00005129
ZX450, ZX480, ZX500-3, ZX520LCH-3/5B, ZX530LCH-5A, ZX600ZX, ZX650H	4473719PS	4473719
ZX650LC-3, ZX670LCR-3/3F/5B/5G, ZX690LCH-5A, ZX800/3, ZX850-3F, ZX870H-5G/5B/5G, ZX890-5A	4473720PS	4473720

\* Attention : SELECTED PARTS may vary depends on machine model and serial number.  
To confirm appropriate SELECTED PARTS for your machine, please contact your local dealer.

Precaution | We recommend that the left and right lower rollers should be replaced at the same time.

# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

## Track link

### For mini/small-size excavators ( ZX-1, 3, 5, 6 type 1.4~8t )

Applicable Models	SELECTED PARTS No.	Number of Links	Genuine Parts No.
ZX27-3	9302915PS	41	9302915
ZX27U-3, ZX29U-3	YD00000165PS	40	YD00000165
ZX30U-3, ZX33U-3, ZX35U-3, ZX38U-3, ZX40UR-3, ZX30U-5A, ZX33U-5A, ZX35U-5A	4736279PS	44	4736279
ZX35U-A, ZX30U-3, ZX30U-3U, ZX35U-3	9187987PS	44	9187987
ZX40U-3, ZX48U-3, ZX50U-3, ZX52U-3, ZX55UR-3	YD00001544PS	38	YD00001544
ZX40U-3, ZX48U-3, ZX50U-3, ZX52U-3, ZX50U-5B, ZX40U-5A, ZX55UR-5B	YD00007403PS	39	YD00007403, 4720489
ZX48U-5A, ZX55U-5A, ZX60-5A, ZX60-5G	9317734PS	38	9317734, 9143849
ZX70, ZX70-3, ZX80LCK-3, ZX70-5A	9156478PS	39	9156478
ZX70LC, ZX75UR, ZX80LCK, ZX70-3, ZX80LCK-3, ZX85US-3, ZX70LC-5G, ZX85USBLC-3	9163908PS	39	9163908

### For mid-size excavators ( ZX-1, 3, 5, 6 type 10~35t )

Applicable Models	SELECTED PARTS No.	Number of Links	Genuine Parts No.
ZX110-1/3	XP00000267PS	41	9179404
ZX120-1/3/5B/6, ZX135US-1/3/5A/5B/6, ZX135UR	XP00000236PS	44	9178845
ZX130LCN-1/3/5B/6	XP00000298PS	46	9229755
ZX110M, ZX130L, ZX130MT, ZX135USL, ZX138MF	XP00000296PS	42	9200212
ZX160	XP00000299PS	43	9200213
ZX180LC, ZX200	XP00000301PS	46	9200210
ZX200LC	XP00000302PS	49	9200211
ZX110M-3, ZX130L-3/5B, ZX135USL-3/5B	XP00000297PS	42	9282299
ZX160-5B/6, ZX160LC-3/5A/5B/5G/6	XP00000300PS	43	9257122
ZX180-5B, ZX180LC-3/5B/5G, ZX190LC-6, ZX200-3/5A/5B/5G/6, ZX225US-3/5A/5B/6, ZX225USR-3/5B/6, X225US, ZX225USR	XP00000244PS	46	9248706
ZX200LC-3/5A/5B/5G/6, ZX225USLC-3/5A/5B/6, ZX225USRL-3/5B/6, ZX225USRLC-3/5B/6, ZX210L-3, ZX225USLC, ZX225USRLC	XP00000245PS	49	9250500
ZX230, ZX240-3/5A/5B/5G/6	XP00000248PS	47	9250491
ZX230LC, ZX240LC-3/5A/5B/5G/6, ZX250L-3	XP00000249PS	51	9250497
ZX270-1/3, ZX280-5B/5G, ZX300-5A/6, ZX330-1/3/5A/5B/5G/6, ZX350-5B	XP00000251PS	45	9248209
ZX270LC, ZX280LC-3, ZX290LC-5B, ZX300LC-6, ZX330LC-1/3/5A/5B/5G/6, ZX350L-3	XP00000252PS	48	9251026

### For large-size excavators ( ZX-1, 3, 5, 6 type 45~87t )

Applicable Models	SELECTED PARTS No.	Number of Links	Genuine Parts No.
ZX450-3/3F, ZX470H-3/5B/5G, ZX490H-5A	XP00000497PS	49	9251216
ZX470LC-5A/5B/5G, ZX490-5A	XP00000512PS	53	9251219
ZX500LC-3/3F, ZX520LCH-3/3F/5B, ZX530LCH-5A	XP00000499PS	49	9259189
ZX670LCH-5G, ZX670LCR-5G, ZX670LC-6, ZX690LCH-5A/6, ZX690LCH-6, ZX690LCR-6	9254119PS	47	9254119
ZX650LC-3, ZX670LCR-3/3F/5B/5G, ZX690LCH-5A, ZX850-3/3F/5B, ZX870-5G	XP00000510PS	47	9252882
ZX870-5B/5G, ZX890-5A	XP00000511PS	51	9252885
ZX450-3, ZX470-5B/6, ZX470H-5B, ZX470R-5B, ZX490H-6, ZX490R-6 600MM(D/G)	9301869PS	49 with shoe	9301869
ZX470LC-5B, ZX470LCH-5B, ZX470LCR-5B, ZX470LC-6, ZX490LCH-6 600MM(D/G)	YA60009480PS	53 with shoe	YA60009480
ZX400LCH-3/5A/5G, ZX400R-3, ZX450-3, ZX470-5B/5G/6, ZX470H-3/5B/5G, ZX470R-3/5B/5G, ZX490H-5A/6, ZX490R-6, ZX520LCH-3, ZX520LCR-3 600MM(T/G)	9251217PS	49 with shoe	9251217
ZX450-3, ZX470H-3, ZX470R-3, ZX470LC-5A/5B/5G/6, ZX470LCH-5B/5G, ZX470LCR-5B/5G, ZX490LCH-5A/6, ZX490LCR-6, ZX500LC-3, ZX500LCK-6, ZX520LCH-3, ZX520LCR-3 600MM(T/G)	9251220PS	53 with shoe	9251220
ZX650LC-3/5B/5G/6, ZX670LCH-3/5B/5G, ZX670LCR-3/5B/5G, ZX690LCH-5A/6, ZX690LCR-6 650MM(D/G)	9261594PS	47 with shoe	9261594
ZX670LC-6, ZX670LCR-3, ZX690LCH-6, ZX690LCR-6, ZX850-3, ZX870-5B/6, ZX870EL-3, ZX870H-3/5B, ZX870R-3, ZX890H-6, ZX890R-6 650MM(D/G)	9261703PS	47 with shoe	9261703
ZX850-3, ZX870H-3, ZX870LC-5/5B/5G/6, ZX870R-3, ZX870LCH-5B, ZX870LCR-5B, ZX890LCH-5A/6, ZX890LCR-6, ZX1000K-3 650MM(D/G)	9261705PS	51 with shoe	9261705

Precaution | We recommend that the left and right track links should be replaced at the same time.

· D/G:Double glouser shoe T/G:Triple glouser shoe

# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

## Track;Link (Unit)

We offer SELECTED PARTS track link inner parts to cope with necessary small parts for SELECTED PARTS track link assy.

\* These inner parts are not compatible with genuine track link.



Representative Models	SELECTED PARTS Track Link (Unit) Part No.	Description	SELECTED PARTS Track Link Assy Parts No.	Representative Models	SELECTED PARTS Track Link (Unit) Part No.	Description	SELECTED PARTS Track Link Assy Parts No.
ZX27-3	XP00000427PS	TRACK-LINK*1	9302915PS	ZX70-3	XP00000460PS	TRACK-LINK*2	9163908PS
	XP00000328PS	BUSHING			XP00000402PS	PIN	
	XP00000398PS	PIN			XP00000412PS	BUSHING;MASTER	
	XP00000413PS	PIN;MASTER			XP00000417PS	PIN;MASTER	
ZX27U-3	XP00000427PS	TRACK-LINK*1	YD00000165PS		XP00000419PS	RING	
	XP00000328PS	BUSHING			XP00000421PS	SPACER	
	XP00000398PS	PIN			XP00000422PS	COLLAR	
	XP00000413PS	PIN;MASTER			XP00000453PS	TRACK-LINK*2	
ZX30U-3	XP00000427PS	TRACK-LINK*1	4736279PS		XP00000369PS	PIN	
	XP00000328PS	BUSHING			XP00000383PS	BUSHING;MASTER	
	XP00000398PS	PIN		XP00000386PS	PIN;MASTER		
	XP00000413PS	PIN;MASTER		XP00000389PS	RING		
ZX33U-3	XP00000428PS	TRACK-LINK*1	9187987PS	XP00000392PS	SPACER		
	XP00000328PS	BUSHING		XP00000395PS	COLLAR		
	XP00000398PS	PIN		XP00000453PS	TRACK-LINK*2		
	XP00000413PS	PIN;MASTER		XP00000369PS	PIN		
ZX40U-3	XP00000457PS	TRACK-LINK*2	YD00001544PS	XP00000383PS	BUSHING;MASTER		
	XP00000423PS	BUSHING		XP00000386PS	PIN;MASTER		
	XP00000399PS	PIN		XP00000389PS	RING		
	XP00000414PS	PIN;MASTER		XP00000392PS	SPACER		
	XP00000418PS	RING		XP00000395PS	COLLAR		
	XP00000420PS	SPACER		XP00000453PS	TRACK-LINK*2		
ZX52U-3	XP00000458PS	TRACK-LINK*2	YD00007403PS	XP00000369PS	PIN		
	XP00000424PS	BUSHING		XP00000383PS	BUSHING;MASTER		
	XP00000400PS	PIN		XP00000386PS	PIN;MASTER		
	XP00000415PS	PIN;MASTER		XP00000389PS	RING		
	XP00000418PS	RING		XP00000392PS	SPACER		
	XP00000420PS	SPACER		XP00000395PS	COLLAR		
ZX60-5G	XP00000459PS	TRACK-LINK*2	9317734PS	XP00000454PS	TRACK-LINK*2		
	XP00000425PS	BUSHING		XP00000370PS	PIN		
	XP00000401PS	PIN		XP00000384PS	BUSHING;MASTER		
	XP00000416PS	PIN;MASTER		XP00000387PS	PIN;MASTER		
	XP00000418PS	RING		XP00000390PS	RING		
	XP00000420PS	SPACER		XP00000393PS	SPACER		
ZX70-3	XP00000460PS	TRACK-LINK*2	9156478PS	XP00000396PS	COLLAR		
	XP00000402PS	PIN					
	XP00000412PS	BUSHING;MASTER					
	XP00000417PS	PIN;MASTER					
	XP00000419PS	RING					
	XP00000421PS	SPACER					

# UNDERCARRIAGE PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
10~35t

ZX-1,3,5,6  
type  
45~87t

Representative Models	SELECTED PARTS Track Link (Unit) Part No.	Description	SELECTED PARTS Track Link Assy Parts No.
ZX200	XP00000454PS	TRACK-LINK*2	XP00000299PS
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	
	XP00000393PS	SPACER	
ZX200	XP00000396PS	COLLAR	XP00000301PS
	XP00000454PS	TRACK-LINK*2	
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	
ZX200	XP00000393PS	SPACER	XP00000302PS
	XP00000396PS	COLLAR	
	XP00000454PS	TRACK-LINK*2	
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
ZX200-3	XP00000390PS	RING	XP00000297PS
	XP00000393PS	SPACER	
	XP00000396PS	COLLAR	
	XP00000455PS	TRACK-LINK*2	
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
ZX200-3	XP00000387PS	PIN;MASTER	XP00000300PS
	XP00000390PS	RING	
	XP00000393PS	SPACER	
	XP00000396PS	COLLAR	
	XP00000455PS	TRACK-LINK*2	
	XP00000370PS	PIN	
ZX200-3	XP00000384PS	BUSHING;MASTER	XP00000244PS
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	
	XP00000393PS	SPACER	
	XP00000396PS	COLLAR	
	XP00000455PS	TRACK-LINK*2	
ZX200-3	XP00000370PS	PIN	XP00000245PS
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	
	XP00000393PS	SPACER	
	XP00000396PS	COLLAR	
ZX200-3	XP00000455PS	TRACK-LINK*2	XP00000248PS
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	
	XP00000393PS	SPACER	
ZX200-3	XP00000396PS	COLLAR	XP00000248PS
	XP00000455PS	TRACK-LINK*2	
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	

Representative Models	SELECTED PARTS Track Link (Unit) Part No.	Description	SELECTED PARTS Track Link Assy Parts No.
ZX200-3	XP00000455PS	TRACK-LINK*2	XP00000249PS
	XP00000370PS	PIN	
	XP00000384PS	BUSHING;MASTER	
	XP00000387PS	PIN;MASTER	
	XP00000390PS	RING	
	XP00000393PS	SPACER	
ZX330-3	XP00000396PS	COLLAR	XP00000251PS
	XP00000456PS	TRACK-LINK*2	
	XP00000371PS	PIN	
	XP00000385PS	BUSHING;MASTER	
	XP00000388PS	PIN;MASTER	
	XP00000391PS	RING	
ZX330-3	XP00000394PS	SPACER	XP00000252PS
	XP00000397PS	COLLAR	
	XP00000456PS	TRACK-LINK*2	
	XP00000371PS	PIN	
	XP00000385PS	BUSHING;MASTER	
	XP00000388PS	PIN;MASTER	
ZX450	XP00000391PS	RING	XP00000497PS XP00000512PS / 9251217PS 9251220PS 9301869PS YA60009480PS
	XP00000394PS	SPACER	
	XP00000397PS	COLLAR	
	XP00000514PS	LINK R/H	
	XP00000518PS	PIN	
	XP00000521PS	PIN;MASTER	
ZX500	XP00000524PS	BUSHING	XP00000499PS
	XP00000527PS	BUSHING;MASTER	
	XP00000530PS	SPACER	
	XP00000533PS	SEAL	
	XP00000536PS	BOLT	
	XP00000538PS	NUT	
ZX650	XP00000551PS	SHOE TG	9254119PS / 9261594PS
	XP00000552PS	SHOE DG	
	XP00000554PS	LINK L/H	
	XP00000515PS	LINK R/H	
	XP00000519PS	PIN	
	XP00000522PS	PIN;MASTER	
ZX650/ZX850	XP00000525PS	BUSHING	XP00000510PS XP00000511PS / 9261703PS 9261705PS
	XP00000528PS	BUSHING;MASTER	
	XP00000531PS	SPACER	
	XP00000534PS	SEAL	
	XP00000555PS	LINK L/H	
	XP00000520PS	PIN	
ZX850	XP00000523PS	PIN;MASTER	XP00000517PS XP00000557PS
	XP00000526PS	BUSHING	
	XP00000529PS	BUSHING;MASTER	
	XP00000532PS	SPACER	
	XP00000535PS	SEAL	
	XP00000537PS	BOLT	
ZX850	XP00000539PS	NUT	XP00000517PS XP00000557PS
	XP00000553PS	SHOE DG	
	XP00000517PS	LINK R/H	
	XP00000557PS	LINK L/H	

\*1 : Track Link is sub-assy with shoe

\*2 : Track Link is sub-assy

# GET PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
12~35t

ZX-1,3,5,6  
type  
45~87t

## GET parts

### For mini/small-size excavators ( ZX-1, 3, 5, 6 type 1.4~8t )

Model Class	SELECTED PARTS No.	Description	Remarks
ZX10-40	4106786PS	ADAPTER;TOOTH	18S type
	4417532PS	ADAPTER;TOOTH	18S type
	4626441PS	CUTTER;SIDE	-
	4626442PS	CUTTER;SIDE	-
	4339868PS	PIN;LOCK	18-20PN
	4339865PS	POINT;TOOTH	18S type
	4339867PS	RUBBER;LOCK	18-20LK
ZX40-60	4245518PS	ADAPTER;TOOTH	18S
	3066997PS	CUTTER;SIDE	-
	3066998PS	CUTTER;SIDE	-
	4622021PS	CUTTER;SIDE	-
	4626430PS	CUTTER;SIDE	-

Model Class	SELECTED PARTS No.	Description	Remarks
EX10-20	4330947PS	ADAPTER;TOOTH	1610T-13V
	4357232PS	PIN;LOCK	V13PN
	4353469PS	POINT;TOOTH	V13S
	XP00000320PS	POINT;TOOTH	V13SYL
	4047569PS	ADAPTER;TOOTH	A1306-25
ZX70-80	4135495PS	ADAPTER;TOOTH	22S type
	3053595PS	CUTTER;SIDE	285A-7-3-5
	3053596PS	CUTTER;SIDE	285A-7-3-6
	4135497PS	PIN;LOCK	22PN
	4135496PS	POINT;TOOTH	22S
	XP00000307PS	POINT;TOOTH	25S
	4135498PS	RUBBER;LOCK	22LK

### For mid-size excavators ( ZX-1, 3, 5, 6 type 12~35t )

Model Class	SELECTED PARTS No.	Description	Remarks
ZX120-130	4366118PS	ADAPTER;TOOTH	20Y-70-14520
	4425500PS	ADAPTER;TOOTH	FT3210T-30
	2015428PS	CUTTER;SIDE	-
	2015429PS	CUTTER;SIDE	-
	XP00000262PS	PIN;LOCK	25-30PN
	XP00000305PS	POINT;TOOTH	30S
	XP00000306PS	RUBBER;LOCK	25-30LK
ZX240	4380336PS	ADAPTER;TOOTH	207-939-5120(45)
	4437208PS	ADAPTER;TOOTH	3809-40ZX
	2021232PS	CUTTER;SIDE	-
	2021233PS	CUTTER;SIDE	-
	4380344PS	PIN	09244-02516
	4512366PS	PIN;LOCK	40PN-P
	4380343PS	POINT;TOOTH	207-70-14151
	4512365PS	POINT;TOOTH	40S
	XP00000324PS	POINT;TOOTH	PC300TL
	XP00000325PS	POINT;TOOTH	PC300RC-N
ZX380-400	4617810PS	ADAPTER;TOOTH	5610T-V43
	4422932PS	PIN;LOCK	V43PN
	4471407PS	POINT;TOOTH	V43RP
	4670449PS	SHROUD	-

Model Class	SELECTED PARTS No.	Description	Remarks
ZX200-220	4363714PS	ADAPTER;TOOTH	20Y-934-2211
	4383046PS	ADAPTER;TOOTH	V29
	4414271PS	ADAPTER;TOOTH	F3610T-35
	2014503PS	CUTTER;SIDE	-
	2014504PS	CUTTER;SIDE	-
	4364125PS	PIN	09244-02496
	4383069PS	PIN	V29PN
	4501627PS	PIN;LOCK	35PN
	4364121PS	POINT;TOOTH	205-70-19570
	4427919PS	POINT;TOOTH	35S
	XP00000321PS	POINT;TOOTH	205-70-19570
	XP00000322PS	POINT;TOOTH	PC200RC-N
	XP00000323PS	POINT;TOOTH	V29SHV
ZX330-350	4501625PS	RUBBER;LOCK	35-40LK
	4383462PS	ADAPTER;TOOTH	-
	4400249PS	ADAPTER;TOOTH	H4110T-V33
	4441323PS	ADAPTER;TOOTH	40S
	4383465PS	PIN;LOCK	V39PN
	4400252PS	PIN;LOCK	V33PN
	4400253PS	POINT;TOOTH	V39RP
	XP00000326PS	POINT;TOOTH	V33SL
	XP00000464PS	POINT;TOOTH	V39TLP
	XP00000467PS	POINT;TOOTH	V39VY

# GET PARTS

ZX-1,3,5,6  
type  
1.4~8t

ZX-1,3,5,6  
type  
12~35t

ZX-1,3,5,6  
type  
45~87t

## For large-size excavators ( ZX-1, 3, 5, 6 type 45~87t )

Model Class	SELECTED PARTS No.	Description	Remarks
ZX450-470	4242623PS	ADAPTER;TOOTH	4756-40
	4350767PS	ADAPTER;TOOTH	6610T-V51
	1010517PS	CUTTER;SIDE	-
	1010518PS	CUTTER;SIDE	-
	4350782PS	PIN;LOCK	V51PN
	4350781PS	POINT;TOOTH	V51SY1
	XP00000327PS	POINT;TOOTH	V51RYL
	XP00000468PS	POINT;TOOTH	V39TLP
	4209167PS	SHROUD	-
	4435856PS	SHROUD	BSH-B500R
	4435857PS	SHROUD	BSH-B500L
ZX600-670	4660436PS	ADAPTER;TOOTH	7110T-V59
	4337184PS	SHROUD	SH6630

Model Class	SELECTED PARTS No.	Description	Remarks
ZX850-870	4472321PS	ADAPTER;TOOTH	6610T-V59
	4472842PS	ADAPTER;TOOTH	8110T-V61
	2016745PS	CUTTER;SIDE	-
	2016746PS	CUTTER;SIDE	-
	4397063PS	PIN;LOCK	V61PN
	4472883PS	PIN;LOCK	V59PN
	4255718PS	POINT;TOOTH	V61RY
	4472424PS	POINT;TOOTH	V59RYL
	4206421PS	SHROUD	SH8130-1
	4262453PS	SHROUD	BSH730A
	4386911PS	SHROUD	-

---

Before using a machine with a telematics communication system, please make sure that the satellite communication system complies with local regulations, safety standards and legal requirements. If not so, please make modifications accordingly.

---

These specifications are subject to change without notice.  
Illustrations and photos show the standard models, and may or may not include optional equipment, accessories, and all standard equipment with some differences in color and features.  
Before use, read and understand the Operator's Manual for proper operation.

